

XL marlin Lighting

Linear Profile 50 (XLLS5075AB) Installation Instruction


The user: thank you for your purchase use this product, read this instruction manual before usage

- 1. Model: XLLS5075AB
- 2. Rated Voltage: 180-240 V 50/60 Hz
- 3. IP Grade: IP44
- 4. Operating Temperature: -20 to +40














- Always disconnect the power supply before installing or performing any maintenance operations.
- Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
- These luminaires are widely used in commercial lighting, home decoration lighting, art gallery and museums.
- Only can be touched after 3 minutes later when power off, so as to avoid burns.
- Dismantling and refit are forbidden
- Installation on inflammables is forbidden.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Surface Mounting Installation

- 1. FIX THE METAL CLIP
- 2. PRESS THE CHANNEL INTO THE METAL CLIP
- 3. CONNECT THE CABLE .
 LIVE LINE FOR L TERMINAL,
 NULL LINE FOR N TERMINAL,
 GROUND LINE FOR E TERMINAL.




Recessed Mounting Installation

- 1.PLACE THE LINEAR IN DESIRED PLACE
- 2.ATTACH THE RECESSED CLIP TO LINEART



4. CONNECT THE CABLE .
LIVE LINE FOR L TERMINAL,
NULL LINE FOR N TERMINAL,
GROUND LINE FOR E TERMINAL.



Pendent Mounting Installation

- 1. DRILL HOLES IN THE CEILING FOR LIFTING WIRE
- 2. FIX LIFTING WIRE INTO CEILING
- 3. SLIDE THE NUT
 FROM THE END OF
 LIFTING WIRE INTO
 THE TRACK OF THE
 PROFILE AND FASTEN IT
- 4. CONNECT THE CABLE .
 LIVE LINE FOR L TERMINAL,
 NULL LINE FOR N TERMINAL,
 GROUND LINE FOR E TERMINAL.

