
The user: thank you for your purchase use this product, read this instruction manual before usage


1. Model: FL1XX



- Always disconnect the power supply before installing or performing any maintenance operations.
- Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
- These luminaires are widely used in commercial lighting, home decoration lighting, art gallery and museums.
- Only can be touched after 3 minutes later when power off, so as to avoid burns.
- Dismantling and refit are forbidden
- Installation on inflammables is forbidden.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.


1. PREPARE THE CEILING
Open a hole according to
the dimension of the
downlight trim that
you choose to be used
with the modular.




110x110mm

2. CONNECT THE CABLE OF THE DRIVER .


Live line for L terminal, Null line for N terminal, Ground line for E terminal.



- 3. CONNECT POWER PLUG OF LED MODULAR to that of the LED driver
- 4. PRESS THE LED FIXTURE TO THE TRIM



5. PUSH THE FIXTURE into the opening



6. CONNECT THE POWER SUPPLY, light up the lamp.

FOR SUITABLE TRIMS FOR THE MO/MX TYPE MODULAR SEE : XL MARLIN LIGHTING CATALOGUE