



XL marlin Lighting

Exterior POLE TOP Lighting (OLPFU) installation Instruction

The user: Thank you for your purchase of this product, read this instruction manual before usage

1. Model: OLPFU
2. Rated Voltage: AC 100-270V, 50/60Hz
3. Rated Power: LED 35W/60W
4. IP Grade: IP65
5. Insulation protection level: Class I
6. Operating Temperature: -30°~50°C


1. Prepare the ground for the depth of foundation pit shall be determined by digging to the original soil. In case of backfill, the recessed box can be embedded only after water injection and settlement.




A

The lamp shall be mounted only when the concrete is completely solidified, and not before settling for 72H (3 days)


2. Place the light on the pole and secure it using screws





3. Connect the cable .
Live line for L terminal,
Null line for N terminal,
Ground line for E terminal.



4. Fix the Pole to the base
Be sure to fasten the flange tightly.



5. Connect the power supply,
light up the lamp.



- Always disconnect the power supply before installing or performing any maintenance operations.
- Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
- These luminaires are widely used in commercial lighting, home decoration lighting, art gallery and museums.
- Only can be touched after 3 minutes later when power off, so as to avoid burns.
- Dismantling and refit are forbidden
- Installation on inflammables is forbidden.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

The light source of this luminaire is not replaceable; when the source reaches its end of life the whole luminaire shall be replaced

Welcome you again to buy our products